

AEG

SOLAR SOLUTIONS AG

Riedweg 3
6418 Rothenthurm
Schweiz / Switzerland

www.aeg-solar.com
plug-in-service@aeg-solar.com

AEG

QUICK INSTALLATION GUIDE FOR THE AS-BBL09 SERIES (AC COUPLED PLUG-IN BATTERY SYSTEM: AS-BBL09-4.8K)


AEG QUICK INSTALLATION GUIDE- SERIES AS-BBL09

VERSION: PD202510 V1-25 EN


Thank you for choosing the reliability of AEG AS-BBL09-4.8K battery system. AEG products are tested and approved by acknowledged independent certification authorities and can only be installed by qualified professional companies.

EN

1. System overview




2. Unboxing




3. Equipment installation

The following steps describe the installation of a AS-BML09-CM and AS-BML09-4.8K as an example. Tools not supplied




Place expansion AS-BML09-4.8K underneath

Position within Wi-Fi coverage for AS-BML09-4.8K to connect to the network. Keep 50mm away from the wall.



Remove rubber plugs:


Remove the silicone pads from the bottom of the AS-BML09-CM and the upper AS-BML09-4.8K in sequence



Note: Do not remove the silicone pad from the bottom-most AS-BML09-4.8K-it is required for water proofing and dust protection.


Mounting and assembly instructions for AS-BML09-CM & AS-BML09-4.8K

Preparation: Back mounting block installation on AS-BML09-CM and AS-BML09-4.8K




Stack with AS-BML09-CM at the Top

Stack expansion batteries in sequence with AS-BML09-CM at the top by inserting the two corresponding ports into each other



4. Electrical connection




5. Device setup

1: Powering On

First, press the AS-BML09-4.8K power button firmly, then press the AS-BML09-CM power button. A distinct tactile click confirms each unit has been successfully powered on.

2: Powering Off

To shut down, press the AS-BML09-CM power button first, followed by the AS-BML09-4.8K. Follow this reverse order to ensure proper system shutdown.




Use the Plug-In Battery App

1 Download the Plug-In Battery app from the App Store (iOS devices) or Google Play (Android devices), or by scanning the QR code.




* For full app instructions, watch the tutorial video on our official website.

2 Add your device.




3 Connect it to the network.



LED Guide

The LED gradually fades in and out in a continuous loop. Green indicates discharging, yellow indicates charging, and red indicates a fault. * Ambient light controllable via app when away





VERSION: PD202510 V1.2-25 DE

DE

AS-EMLO9 Serie
AEG

Stromnetz

Verzweilkasten

Intelligenter Zähler

Stromnetz

Intelligente Steckdose

Hausnet

(AS-EMLO9-4.8C erweiterbar auf 14.4 kWh mit 3 Batterien)

AS-BML09-CH AS-BML09-CH1 H&D Kombiarte Plötze Schraube M6		AS-BML09-4.8K AS-BML09-4.8K H&D Kombiarte Plötze Schraube M6	
 2 in AC-Kabel1 H&D Kombiarte Plötze Schraube M6		 H&D Kombiarte Plötze Schraube M6	

Halten Sie auf den Seiten einen Abstand von 50 mm zur Wand ein.



VERSION: PD202510 V1-25 NI

NL

[illegible]

AS-BML09-CH		AS-BML09-4.8K	
AEG	1 in AEG Kapsel	Achtermontageboort	AS-BML09-4.8K
MS-12 geïmbedeerde Philips schroefboort	Document	MS-12 geïmbedeerde Philips schroefboort	MS-12 zelfregulende spakenschroefboort

AS-BML09-CM

430mm

170mm

AS-BML09-4.8K

450mm

175mm

Pen

Krulspijkerwinder/saier
(PH1 en PH2)

Hamer

Boormachine
(boorbit: 10 mm)

Steekelusnel
(13 mm)